

Stormsaver: StormStation Rainwater Harvesting System Schematic

1. Rainwater is collected from roof area
2. Rainwater passes through pre-tank filter
3. StormStation rainwater storage tank with inlet calmer & suction filter
4. Overflow from storage tank with NRV to drain
5. Internal rainwater booster set
6. StormStation Control Panel
7. Local power supply
8. 50mm Black & Green MDPE boosted rainwater supply to building
9. Mains cold water supply (top up)
10. Optional photovoltaics
11. Optional monitoring unit
12. Points of use

Disclaimer

This schematic is to be used as a general overview of a typical Stormsaver Water Reuse System layout. It is not site specific and should not be relied upon for technical submittal or installation guidance.



Water Reuse Specialists

T: 01636 815 254

W: www.stormsaver.com

The system design rights and copyright remains the property of Stormsaver Ltd. Contact us on 01636 815 254 for more details www.stormsaver.com