

Stormsaver: COMBI Rainwater Harvesting System Schematic

1. Rainwater is collected from roof area
2. Rainwater passes through pre-tank filter
3. Above-ground rainwater storage tank
4. Inlet calmer
5. Overflow from rainwater storage tank with NRV
6. Submersible pump (optional standby)
7. Floating suction filter
8. 50mm Black & Green MDPE piped supply to building
9. Optional micron filtration
10. Stormsaver Control Unit - COMBI
11. Mains cold water supply (top up)
12. COMBI overflow connection to drain
13. Local power supply
14. Optional BMS (by others)
15. Optional UV disinfection unit
16. Boosted rainwater supply
17. Optional monitoring unit supplied with Rainwater & Mainswater meters
18. Points of use

Disclaimer

This schematic is to be used as a general overview of a typical Stormsaver Water Reuse System layout. It is not site specific and should not be relied upon for technical submittal or installation guidance.



Water Reuse Specialists

T: 01636 815 254

W: www.stormsaver.com

The system design rights and copyright remains the property of Stormsaver Ltd.
 Contact us on 01636 815 254 for more details www.stormsaver.com